

WHITE a82w151				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1		2	1	1
G2				1
Y3		1		

DARK BROWN a82t00154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1	2	18		1
N1	8	34		
R2		10	1	1

BLACK a82t154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		21	1	1
B1	8	26		1
L1	2	15	1	

CHESTNUT BROWN a82t154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		4		1
B1		60		1
R3	4	2		
Y3	2	61		

Thermacore Brown before 2013

TERRA BRONZE a82w153				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1	4	22		
N1		22	1	1
R2		12		1
Y3	2	6	1	1

SANDSTONE a82w153				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		42		
B1		41	1	1
R2		6		
Y3		37	1	

GRAY a82w151				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1	4	14		
R2		6		
Y3		36		
R3		12		
L1		3		

TAUPE/391 SAND a82w00153				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1	2	15	1	
B1		30		
R2		6		
Y3		28		
G2		2	1	

Traditional Doors only

color formulas revised 05/30/14

HUNTER GREEN a82t154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		5	1	1
B1	2	32		
L1	4	5	1	
Y3	2	20		1

ALMOND a82w151				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1		3		
R2		1		
Y3		15		1

DESERT TAN a82w00151				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
N1	2	49		1
R3		3		1
Y3		6	1	
G2		1		

PAINTING INSTRUCTIONS FOR STEEL DOORS

- 1- Use a Paint De-Glosser on the door in place of a primer coat (apply the de-glosser to only one section of the door at a time).
- 2- Within one hour of applying the de-glosser the section must have a coat of paint applied (the surface of the section is very porous at this stage & the coat of paint acts as a sealer).
- 3- Follow label directions and apply as many top coats as necessary for a quality job, make sure to wait the recommended time between top coats.

The Genuine. The Original.



Overhead Door Company of Kansas City
A **DHPACE** Company